





MAPEGROUT ANCHOR & REPAIR

REPAIR WORKS



Fibre-reinforced, compensated-shrinkage mortar for repairing concrete and anchoring metal structures by pouring the mortar into specially prepared areas.

WHERE TO USE



- Repairing badly damaged structures that require the use of free-flowing mortar.
- Structural reintegration of pillars, beams and reinforced concrete walls by pouring the mortar into formwork.
- Reintegrating floor slabs after removing damaged areas by scarifying.
- □ Repairing concrete floors.
- ☐ Reintegrating **concrete steps**.

ANCORING WORKS



When mixed with water, **Mapegrout Anchor & Repair** forms hi-flow mortar applied in a single layer at a thickness of 5 cm, after having prepared the substrate.

WHERE TO USE



- Anchoring metal structures.
- ☐ Filling rigid joints between concrete elements.
- □ Footings for masonry.
- Anchoring machine tools by casting the mortar below the machine base.
- ☐ Anchoring **metal structures**.

EVERYTHING'S **OK**, WITH **MAPEI**

HEAD OFFICE MAPEI S.p.A.

Via Cafiero, 22 - 20158 Milan Tel. +39-02-37673.1 Fax +39-02-37673.214 Internet: www.mapei.com E-mail: mapei@mapei.it

