


Products for the Installation of Timber Flooring





***Products for the installation of
Timber Flooring***



● **PRIMERS**

1

● **ADHESIVES**

2

● **REPAIR AND
SMOOTHING
COMPOUNDS**

3

● **MOISTURE
VAPOUR
BARRIER**

4

● **LEVELLING
COMPOUNDS**

5

PRIMERS



Eco Prim T

All purpose solvent-free neoprene primer to improve the adhesion of levelling compounds on all absorbent and non-absorbent substrates - **very low VOC**



Mapeprim SP

Two-component, solvent free primer to ensure perfect bonding with smoothing and levelling compounds and cementitious mortars on non-absorbent and difficult substrates - **very low VOC**

MOISTURE VAPOUR BARRIER



Planiseal EMB (A+B)


High performance 100% solids, two-part epoxy, one-coat moisture barrier system for concrete slabs that exhibit MVER's up to 100% R.H

ADHESIVES FOR TIMBER AND PARQUETRY FLOORING



Ultrabond P990 1K

One-component, ready-to-use, solvent-free elastic polyurethane adhesive with an extremely low emission level of volatile organic compounds for pre-finished, multi-layered and traditional jointed solid timber flooring. Suitable for heated screeds.



Ultrabond Eco S955 1K

One-component, isocyanate and solvent-free, sililated polymer adhesive with very low emission level of volatile organic compounds (VOC), for all types of parquetry. Suitable for heated screeds.

REPAIR & SMOOTHING COMPOUNDS



Nivorapid

Ultra-fast setting thixotropic cement-based levelling mortar for horizontal or vertical surfaces



Latexplan Trade

Two part smoothing/levelling compound. 1-10mm in one application. Suitable for wheeled traffic. Can be walked on after 2 hours



Mapecem Quickpatch

High performance, high flow concrete patching compound

LEVELLING COMPOUNDS




Latexplan Trade



- ▶ Two-part, smoothing and levelling compound particularly suitable for levelling timber substrates
- ▶ **Thickness per coat:** 1 to 10 mm
- ▶ **Setting time:** 45 - 60 minutes
- ▶ **Light foot traffic:** 1.5 - 2 hours
- ▶ **Install flooring:** 12 hours




Ultraplan



- ▶ Ultra-fast hardening self-levelling smoothing compound especially suitable for areas subject to wheeled chairs.
- ▶ **Thickness per coat:** 1 to 15 mm
- ▶ **Setting time:** 50 - 70 minutes
- ▶ **Light foot traffic:** 3 hours
- ▶ **Install flooring:** 12 hours



UC Leveller



- ▶ Fast hardening levelling smoothing compound recommended for pumping.
- ▶ **Thickness per coat:** 3 to 70 mm
- ▶ **Setting time:** 2 - 4 hours
- ▶ **Light foot traffic:** 12 hours
- ▶ **Install flooring:** 24 hours



Ultraplan Maxi



- ▶ Ultra-fast hardening self-levelling smoothing compound suitable to install all types of flooring where resistance to loads and traffic is required.
- ▶ **Thickness per coat:** 3 to 30 mm
- ▶ **Setting time:** 50 - 70 minutes
- ▶ **Light foot traffic:** 3 hours
- ▶ **Install flooring:** 1 - 3 days



Ultraplan Eco



- ▶ Ultra-fast hardening self-levelling smoothing compound with very low emission of volatile organic compounds (VOC).
- ▶ **Thickness per coat:** 1 to 10 mm
- ▶ **Setting time:** 50 - 70 minutes
- ▶ **Light foot traffic:** 3 hours
- ▶ **Install flooring:** 12 hours
(24 hours for timber floors)

Primers

		Absorbent concrete	Non - absorbent concrete	Ceramics	Steel
	Eco Prim T	<input checked="" type="checkbox"/> *	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
	Mapeprim SP		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

* Dilute **Eco Prim T** with two parts water

☒ RECOMMENDED



Adhesives

		Large solid timber planks with tongue and groove joints	Pre-finished solid and engineered timber and parquet flooring with tongue and groove joints	Pre-finished and solid	Small solid timber planks (raw) without tongue and groove joints
	Ultrabond P990 1K	<input type="checkbox"/>	<input type="checkbox"/>		
	Ultrabond Eco S955 1K	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

☐ RECOMMENDED



Repair and Smoothing Compounds

		Thickness of repair	Time required before flooring installation
	Nivorapid	3-20mm	4-6 hours
	Nivorapid & Latex Plus	3-20mm*	12-24 hours
	UC Leveller	3-70mm	24 hours

* Not bonded, only floating as described in the technical data sheet for Latex Plus



4

Moisture Vapour Barrier

		Substrate	RH \leq 90% (ASTM 2170) Film Thickness	RH $>$ 90% - $<$ 95% Film Thickness	RH $>$ 95% - $<$ 100% and rising damp
	Planiseal EMB	Green Concrete	0.25mm	0.33mm	0.46mm



Levelling Compounds

		Thickness per application	Min Thickness	Substrate			
				Concrete	Ceramics	Steel	Timber
	Latexplan Trade	1-10mm	3	<input type="checkbox"/>	<input type="checkbox"/> Δ	<input type="checkbox"/>	<input type="checkbox"/>
	UC Leveller *	3-70mm	3	<input type="checkbox"/>	<input type="checkbox"/> Δ		
	Ultraplan	1-15mm	3	<input type="checkbox"/>	<input type="checkbox"/> Δ		
	Ultraplan Eco	1-10mm	3	<input type="checkbox"/>	<input type="checkbox"/> Δ		
	Ultraplan Maxi	3-30mm	3	<input type="checkbox"/>	<input type="checkbox"/> Δ		

* Deep fill levelling and smoothing compound that must be covered by at least 3mm of the Ultraplan range

Δ Must use recommended Mapei primer

☐ RECOMMENDED





	PRODUCTS FOR CERAMICS AND STONE MATERIALS
	PRODUCTS FOR RESILIENT AND TEXTILE MATERIALS
	PRODUCTS FOR WOODEN FLOORING
	PRODUCTS FOR CEMENTITIOUS AND RESIN FLOORING
	PRODUCTS FOR ACOUSTIC INSULATION
	PRODUCTS FOR BUILDING
	ADMIXTURES FOR CONCRETE
	PRODUCTS FOR STRUCTURAL STRENGTHENING
	PRODUCTS FOR THE REPAIR OF MASONRY
	PRODUCTS FOR THERMAL INSULATION
	WALL PROTECTIVE AND DECORATIVE COATINGS
	PRODUCTS FOR WATERPROOFING
	PRODUCTS FOR UNDERGROUND CONSTRUCTIONS
	ELASTIC SEALANTS AND ADHESIVES
	GRINDING AIDS FOR CEMENT

MAPEI Australia Pty Ltd
 12 Parkview Drive
 Archerfield Qld 4108
 Phone: 07 3276 5000
 Fax: 07 3276 5076
 Email: sales@mapei.com.au
 Website: www.mapei.com.au

