






SYSTEM FOR THE FAST TRACK INSTALLATION OF TILES IN INTERNAL WET AREAS



















rubber tane Mapeband Easy primary waterproofing membrane Mapelastic AquaDefense

bonding slurry
Planicrete SP mixed with Mapecem

Mapecem Pronto

secondary waterproofing Mapelastic AquaDefense

adhesive Rapid S1 Tile Adhesive grout
Ultracolor Plus

Mapesil AC Mapesil LM

٦

2

3

5

6

8

9

Ceramic/Stone System – Internal Fast Track System for Waterproofing & Tiling Bathroom

MAPEI: H07

Version: 04/04/2023

Revision: C

0

PART 1 SYSTEM

1.1 INFORMATION

- This work method statement covers the fast track systems for waterproofing and tiling bathrooms, in accordance with industry best practice, relevant standards and as per MAPEI technical data sheets (TDS).
- MAPEI provides technical data sheets (TDS) and safety data sheets (SDS) for all products which should be read in conjunction with this Work Method Statement (WMS). Where necessary, conduct a chemical risk assessment and SWMS to ensure each products' correct and safe use. These documents can be obtained from www.mapei.com.au, or by clicking directly on the products listed within the PDF.
- Products in this WMS can contribute towards satisfying the relevant Green Star credits. The VOC content of products can be found under section 9 on the product SDS, while VOC emissions certificates can be found on the product webpage.

1.2 USER NOTES

1.3 RELEVANT DOCUMENTATION

- A. Australian Standard(s):
 - 1. AS 3958.1-2007 Ceramic Tiles; Part 1: Guide to the Installation of Ceramic Tiles
 - 2. AS 3740-2021 Waterproofing of domestic wet areas
- B. MAPEI Technical Notebook(s):
 - 1. Ceramic Substrate Preparation Guide
 - 2. Guide for the Installation of Ceramic Materials
 - 3. Grout Troubleshooting Guide
 - 4. Laying Stone Materials
- C. Other References:
 - 1. ASAA Natural Stone Manual

This Work Method Statement (WMS) provides general recommendations only and is not intended to be interpreted as a generic specification for the application/installation of the listed products. As each project differs in exposure and site conditions, specific recommendations may vary from the information contained above. For recommendations for specific applications/installations please contact MAPEI Australia Pty Ltd.



Ceramic/Stone System – Internal Fast Track System for Waterproofing & Tiling Bathroom

MAPEI: H07

Version: 04/04/2023

Revision: C

1.4 SUBSTRATE PREPARATION

All substrates must be structurally sound, dry, solid and stable. Any dust, grease, oil, paint, old coatings or curing compounds present on the surface of the surface that may inhibit bond, shall be mechanically removed. The substrate should then be cleaned and prepared in accordance with the relevant standards and as per the MAPEI technical data sheets (TDS).

1.5 WATERPROOFING MEMBRANE – BELOW SCREED OPTIONAL

NOTE: Prior to the application of the waterproofing membrane:

- Ensure a waterproofing bandage has been applied with **MAPEBAND EASY** at wall/wall, wall/floor junctions and all other areas where movement is expected.
- Ensure all pipe penetrations & angles are primed **ECO PRIM GRIP** to create a suitable mechanically keyed surface prior to the waterproofing. Ensure penetrations are appropriately detailed.

A. MAPELASTIC AQUADEFENSE

Ready-to-use, ultra-quick drying, flexible liquid membrane for internal and external waterproofing applications. Applied at a minimum 0.4 mm per coat.

APPLICATION:

- Waterproofing membrane must be applied to walls and floors in a minimum of two even coats to form a final flexible, continuous dry film thickness of 0.4 mm per coat
- (FC Sheeting) It is recommended to reinforce with **MAPETEX 50** at the sheet joints by embedding in the first membrane coat in accordance with the TDS. Optionally can also be used to reinforce the entire layer of membrane.

1.6 SCREED

A. MAPECEM PRONTO

Pre-blended, ready-to-use, quick-setting and drying (24 hours), controlled-shrinkage mortar for screeds.

APPLICATION:

- Ensure a slurry coat of **PLANICRETE SP** mixed with **MAPECEM** has been applied. Refer to the TDS for mixing details.
- Mix MAPECEM PRONTO apply in strict accordance with the TDS paying particular attention to the surrounding environmental conditions.
- Ensure screed is applied over the slurry coat whilst the slurry coat is still wet.
- Ensure a minimum thickness of 10 mm is applied.
- Create adequate falls in accordance with the relevant standard.



Ceramic/Stone System – Internal Fast Track System for Waterproofing & Tiling Bathroom

MAPEI: H07

Version: 04/04/2023

Revision: C

1.7 WATERPROOFING MEMBRANE — ABOVE SCREED

NOTE: Prior to the application of the waterproofing membrane, ensure a waterproofing bandage has been applied with **MAPEBAND EASY** at wall/wall, wall/floor junctions and all other areas where movement is expected.

A. MAPELASTIC AQUADEFENSE

Ready-to-use, ultra-quick drying, flexible liquid membrane for internal and external waterproofing applications. Applied at a minimum 0.4 mm per coat.

APPLICATION:

• Waterproofing membrane must be applied to walls and floors in a minimum of two even coats to form a final flexible, continuous dry film thickness of 0.4 mm per coat

1.8 ADHESIVE

A. RAPID SI TILE ADHESIVE

One component, high performance and fast setting cementitious adhesive with no vertical slip.

APPLICATION:

- Some natural stones can be prone to warping and staining, therefore MAPEI recommends when using natural stone to consult the manufacturer/supplier for any recommendations or guidelines. Adhesive selection for natural stone is also dependant on its moisture sensitiveness, which is represented by a class system. Please refer to EN14617 and MAPEI technical notebook: Laying Stone Materials for more information.
- Prepare and mix adhesive in strict accordance to the packaging and TDS.
- To ensure good adhesion, apply with pressure a thin coat of the adhesive with the straight edge of the trowel. Immediately follow this with a layer of adhesive at the correct thickness using a suitable notched trowel
- Adhesive should also be pressure applied to the back of the tile/stone with a thin coat using the straight edge of the trowel (back-buttering).
- Ensure the adhesive stays "fresh" and does not form a skin, especially in hot environments, prior to the application of the tile/stone.
- Place the tile/stone firmly into position wet-on-wet with a slight back and forward motion perpendicular to the trowel lines to collapse the notches.
- It is recommended to periodically remove and assess adhesive coverage. Continue if acceptable, otherwise reassess trowel and application technique.



Ceramic/Stone System – Internal Fast Track System for Waterproofing & Tiling Bathroom

MAPEI: H07

Version: 04/04/2023

Revision: C

0

1.9 GROUT

NOTE: To estimate the consumption rate according to specific project data, use the **MAPEI GROUTS AND SEALANTS CALCULATOR**.

A. ULTRACOLOR PLUS

High-performance, anti-efflorescence, non-irritating quick-setting and drying polymer-modified mortar with water-repellent DropEffect® and mould resistant BioBlock® technology for grouting joints from 2 to 20 mm wide.

APPLICATION:

- Ensure the joints are clean, free of dust and empty down to at least 2/3 of the thickness of the tiles. It is then suggested to carry out a 1 m² sample area, along with the silicone, to check cleanability and for approval by the designer.
- Mix the grout and fill the joints completely using a trowel or rubber float. Ensuring the joints are completely compacted with no unevenness.
- Remove excess grout while still fresh from the surface of the tile/stone by moving the float diagonally across the joints.
- When the grout loses plasticity and becomes opaque, clean excess grout with a hard, damp sponge working diagonal to the joints. Rinse sponge regularly using clean water.

1.10 SILICONE

Silicone to be selected from the below options:

A. MAPESIL AC

Pure, mould-resistant, acetic, silicone sealant available in 40 colours.

B. MAPESIL LM

Neutral mould resistant silicone sealant for stone and marble.

APPLICATION:

• Movement joints should be installed in accordance with AS 3958.1-2007.









SYSTEM FOR THE **FAST TRACK INSTALLATION OF TILES IN INTERNAL WET AREAS**

Product Guide



Mapeband Easy

Size	Barcode
10 m	8022452113406
30 m	8022452113413



Mapecem Pronto

Size	Barcode
20 kg	9345490000552



Mapelastic Aquadefense

Size	Barcode
15 kg	8022452056055



Rapid S1 Tile Adhesive

Size	Barcode
20 kg	9345490002976



Planicrete SP

Size	Barcode
25 kg	9345490000453



Ultracolor Plus

Size	Barcode
2 kg	Refer to Mapei Price List for
5 kg	the entire range and barcodes.



Mapecem

Size	Barcode
20 kg	9345490000682



Mapesil AC or Mapesil LM

Size	Barcode
310 ml	Refer to Mapei Price List for the entire range and barcodes.

